DISASSEMBLY OF DOOR

1) Remove the manual door lock switch. Use a small flat head screwdriver to carefully work around the edge to remove.



2) 2 screws located around the armrest hold the panel in place, you'll see the second one after you disconnect the window/lock controls.

3) Remove the window/lock controls by pulling up on the outside edge of the unit. Unplug the connection for the power windows, door locks.



4) Remove top triangular piece opposite the outside mirror. Pull from the front and back edges and piece should pop out.

5) Remove the door handle bezel. Pull out from the backside of the panel and the two clips will pop out. (See picture)



6) Lift straight up on door panel and it will come off. You can see the white hooks on the back of the door panel in the picture.

7) Disconnect door courtesy light. Reach in after you lift the door panel up and remove the light connection.

